Very Cool Flat MagFix

MAN & MACHINE

Feel the attraction! Magnets are integrated inside this hygienic keyboard, for easy attachment to magnet sensitive surfaces.

This generously sized keyboard is washable because its internal electronics are safely sealed. Its sterilisable drape keeps germs out. Discover all features that make this keyboard so perfectly suited for use in medical and other hygiene sensitive settings.



CLEAN HYGIENICALLY WASHABLE

To fit your cleaning protocol, keyboard and drape may both be dipped, rinsed, sprayed, or wiped with soap and water as well as approved cleaning fluids.



SMART CABLE QUICK INSTALL

For easy cable management, Very Cool Flat comes standard with a 45 cm cable that can be led in 4 directions, plus a 150 cm extension cable which can be guided into a cart, desk or wall. Its easy-disconnect cable has double strain relief to maximise durability.



The keyboard resists most common surface disinfectants, allowing you not only to clean it, but also disinfect it. Treat it just like any other high frequency touch surface in your facility.



STERILISABLE DRAPE GERM BARRIER

The fitted drape prevents bacteria from entering between keys. It can be sterilised in an autoclave or thermo disinfector for the ultimate clean.



No need to disconnect during cleaning. Hold down F11 key for 3 seconds to lock or unlock and secure your data during keyboard treatment.



HYGIENIC WHITE PROMOTE INFECTION CONTROL

For a fresh and clean look, and to easily detect contamination and respond instantly, Very Cool Flat features a hygienic white exterior.



Enjoy the tactile feedback of this keyboard offered by its full travel mechanical keys. The drape has a slight relief for easy finger positioning and blind typing.





SAFE CHOICE FREE OF ANTIMICROBIAL COATING

We choose not to use antimicrobial coatings to avoid any risk of potential harm to users or to the environment.

Very Cool Flat MagFix

Cleaning Specifications

CLEANING FLUIDS ALLOWED



Soap and water.



Approved surface disinfectants, such as those based on alcohol, chlorine $\le 10\%$, formaldehyde $\le 37\%$, glutaraldehyde, phenol or quaternary ammonium $\le 2\%$, or oxidising ≤ 3 .

CLEANING METHODS ALLOWED



You can wipe the product with a soft cloth that is non-abrasive like a microfiber cloth, a disinfecting wipe, a soft brush similar to a paint brush in bristle stiffness or a sponge, but not a scourer of any sort.



You can spray the product.



You can rinse the product.



You can briefly immerse the product, except the USB connector.

STERILISATION METHODS FOR DRAPES



You can sterilise the product in an autoclave or thermo disinfector (up to 134 $^{\rm o}$ C, tested 200 cycles).



You can expose the product to Hydrogen Peroxide Vapour (HPV).

Product Specifications

PRODUCT DESCRIPTION	Full size keyboard with sealed-in magnets for attachment.
	Includes numeric keypad and drape
MATERIAL COMPOSITION	Open style hard plastic, silicone sealed interior,
	latex-free silicone drape
IP RATING	IP68
WARRANTY	2 year
COMPLIANCE	CE, EMS, WEEE, RoHS, REACH, FCC
COLOUR	Hygienic white
SIZE	42 x 15.2 x 2.3 cm
WEIGHT	565 g, 665 g with drape
CABLE LENGTH	Cable: 0.45 m; Extension cable (included): 1.5 m
STORAGE TEMPERATURE	0 °C to 70 °C
OPERATING TEMPERATURE	0 °C to 70 °C
POWER	5V, 50 mA
COMPATIBILITY	Windows, Mac & Linux
CONNECTOR	USB
ORIGIN	Made to our specifications in China
LAYOUT	104 keys with standard numeric keypad
LANGUAGE LAYOUT	Arabic, Belgian (Azerty), French (Azerty), German, Greek, Italian,
	Nordic (Danish, Norwegian, Swedish, Finnish), Portuguese, Spanish
	Swiss/Luxembourg, Turkish, UK, US International (Qwerty)
	· · · · · · · · · · · · · · · · · · ·



Europe: USA: info@mmieu.com

info@mmimd.com

+31 (0) 23 5450185 +1 301 341 4900